



NOTES:

1. Preferred piping layout.

2. The temperature and pressure relief valve setting shall not exceed pressure rating of any component in the system.

3. Service valves are shown for servicing boiler. However, local codes shall govern their usage.

December 2011 | Printed in U.S.A. | © A. O. Smith

For Technical Information and Automated Fax Service, call 800-527-1953 or visit www.hotwater.com. A. O. Smith Corporation reserves the right to make product changes or improvements without prior notice.