



## NOTES:

1. Preferred piping layout.

- 2. The temperature and pressure relief valve setting shall not exceed pressure rating of any component in the system.
- 3. Service valves are shown for servicing boiler. However, local codes shall govern their usage.

December 2011 | Printed in U.S.A. | © A. O. Smith

For Technical Information and Automated Fax Service, call 800-527-1953 or visit www.hotwater.com. A. O. Smith Corporation reserves the right to make product changes or improvements without prior notice.